

## ※ 產品說明 ※

1 LED	ON/OFF	CDT3158, CDT3258, CDT3332	P.1,
	ONE SHOT	CDT3195, CDT3260, CDT3332	P.1, P.2
2 LED	ON/OFF	CDT3200	P.2
	LEVEL HOLD	CDT3200 CDT7101, CDT3119, CDT3196	P.2, P.12
3 LED	ON/OFF	CDT3241, CDT3261, CDT3176	P.4
	ONE SHOT	CDT3157, CDT3189, CDT3234	P.3
4 LED	2 LED CHASING	CDT3119	P.12
5 LED	LEVEL HOLD	CDT3155, CDT3224	P.5
	ROM CODE	CDT3127, CDT3211, CDT3331, CDT3229, CDT3299	P.5, P.9
6 LED	ON/OFF	CDT3159, CDT3205, CDT3259, CDT3269, CDT3334	P.6, P.7
	ONE SHOT	CDT3162, CDT3262, CDT3282	P.6, P.7, P.8
	ROM CODE	CDT3197	P.8
腳踏車前燈	燈泡, LED	CDT3176	P.11
	燈泡+電壓偵測	CDT3206, CDT3272	
腳踏車後燈	ROM CODE	CDT3127, CDT3211, CDT3331	P.9
汽車煞車燈 IC	10 個輸出	CDT7250	P.13
漸明漸暗	1 個輸出	CDT3199	P.12
	4 個輸出	CDT3063, CDT3143, CDT3253	P.12
倒時定時器 IC	有 LCD	CDT3050, CDT5201	P.10, P.11
	沒有 LCD	CDT3260, CDT3332, CDT3215 CDT3162, CDT3262, CDT3282	P.1 P.6, P.7, P.8
馬達正反轉 IC		CDT3119	P.12
樂透 IC	6/12 個輸出	CDT3096	P.12
計步器 IC	5 位數	CDT3194	P.13
音樂 IC	TO-92 包裝	CDT5202	P.13
電壓偵測 IC	TO-92 包裝	CDT7230	P.13
警報器 IC	3 種警報聲	CDT3297	P.14
	BiBi 聲	CDT3298	P.14
聖誕燈控制器 IC	AC 用 - SCR	CT-23,.... CT-88	P.15

## ※ STANDARD PRODUCTS ※

1 LED	ON/OFF	CDT3158, CDT3258, CDT3332	P.1, P.2
	ONE SHOT	CDT3195, CDT3260, CDT3332	P.1
2 LED	ON/OFF	CDT3200	P.2
	LEVEL HOLD	CDT3200 CDT7101, CDT3119, CDT3196	P.2, P.12
3 LED	ON/OFF	CDT3241, CDT3261, CDT3176	P.4
	ONE SHOT	CDT3157, CDT3189, CDT3234, CDT3255	P.3
4 LED	2 LED CHASING	CDT3119	P.12
5 LED	LEVEL HOLD	CDT3155, CDT3224	P.5
	ROM CODE	CDT3127, CDT3211, CDT3331, CDT3229, CDT3299	P.5, P.9
6 LED	ON/OFF	CDT3159, CDT3205, CDT3259, CDT3269, CDT3334	P.6, P.7
	ONE SHOT	CDT3162, CDT3262, CDT3282	P.6, P.7, P.8
	ROM CODE	CDT3197	P.8
BIKE FRONT LAMP	LAMP, LED	CDT3176	P.11
	LAMP + VOLTAGE DETECTOR	CDT3206, CDT3272	
BIKE BACK LAMP	ROM CODE	CDT3127, CDT3211, CDT3331	P.9
CAR BRAKE LAMP	10OUTPUTS	CDT7250	P.13
FADING	1 OUTPUT	CDT3199	P.12
	4 OUTPUTS	CDT3063, CDT3143, CDT3253	P.12
DOWN TIMER	WITH LCD	CDT3050, CDT5201	P.10, P.11
	WITHOUT LCD	CDT3260, CDT3332, CDT3215 CDT3162, CDT3282, CDT3345	P.1 P.6, P.7, P.8
MOTOR		CDT3119	P.12
LOTTERY GAME	6/12 OUTPUTS	CDT3096	P.12
STEP COUNTER	5 DIGITS	CDT3194	P.13
MELODY	TO-92 PACKAGE	CDT5202	P.13
VOLTAGE DETECTOR	TO-92PACKAGE	CDT7230	P.13
SIREN	3 SOUNDS	CDT3297	P.14
	BiBi ALARM	CDT3298	P.14
X'MAS LAMP	AC用 - SCR	CT-23,.... CT-88	P.15